



Decal Application Instructions - Wet Format

12" x 12" or Larger

Preparation of surface:

Thoroughly clean and dry the application surface with a wetting solution such as a very mild mixture of household detergent and water. For best results, the application surface and surrounding environment temperature should be 50° F or higher. If application is being made at a temperature below 50°, the application surface should be cleaned with rubbing alcohol prior to applying the wetting solution for proper adhesion.



Application Instructions:



Mark the desired decal position. Place the decal face down on a flat surface and carefully remove the paper backing.



Using a sponge, flood the application surface and adhesive side of the decal with the wetting solution.



Position the decal on the application surface.



Squeegee from top to bottom with light overlapping strokes.



Dry the entire area with a clean, soft cloth and re-squeegee the decal with firm strokes, starting in the center of the decal and working outwards towards each edge.



Allow the decal 24 hours to adhere, then re-squeegee. Ultimate adhesion will occur approximately 24-48 hours after initial application.